







FH-5551

FH high-speed / high performance / extended storage, controller 4-core, NPN/PNP, 2 cameras, W10 IoT Enterprise LTSC
2019 64bit

Specifications

Performance	Very high
Processor family	Intel® Core™ i7
Operating system	Windows 10 IoT Enterprise 2019 LTSC - 64 bit
Memory	32 GB RAM (non ECC)
AI Scratch detection filter	✓
AI FineMatching	✓
Number of cameras	2
Integrated monitor	✗
Communication port(s)	EtherCAT Slave, EtherNet/IP, Ethernet TCP/IP, PROFINET Slave, Serial RS-232C, USB
Output type	PNP/NPN
Application	2D Robot guidance, 3D Bin picking, AI fine matching, AI scratch detection, Bead inspection, Code reading, Code verification, Color inspection, Counting, Defect inspection, Measurement inspection, OCR / OCV, Presence / Absence

Accessories

	FH-MT12	Vision system FH touch panel monitor 12-inch
	FH-UMAI1	AI filter installer for FH controller. USB license key dongle
	FH-VMDA 2M	Vision system accessory FH conversion cable monitor DVI-RGB 2 m
	FH-VMDA 5M	Vision system accessory FH conversion cable monitor DVI-RGB 5 m



FH-VUAB 2M

Vision system accessory FH USB cable touch panel 2 m



FH-VUAB 5M

Vision system accessory FH USB cable touch panel 5 m



FZ-MEM16G

Accessory FH, USB memory 16G



GX-JC03

3-port EtherCAT Junction module, 24 VDC power supply



GX-JC06

6-port EtherCAT Junction module, 24 VDC power supply

HMC-SD293

SD memory card, 2 GB

HMC-SD493

SD memory card, 4 GB



W4S1-05D

5-port enhanced Ethernet switch

XW2Z-050EE

Parallel I/O cable for terminal block XW2R-_34G-T, 0.5 m

XW2Z-100EE

Parallel I/O cable for terminal block XW2R-_34G-T, 1 m

XW2Z-200EE

Parallel I/O cable for terminal block XW2R-_34G-T, 2 m

XW2Z-300EE

Parallel I/O cable for terminal block XW2R-_34G-T, 3 m



XW2Z-S013-2

Parallel I/O cable, 2m, for FH series only



**EAC Mark removal
Discontinuation Notice**

EN PDF 221 KB



**FH Series Vision System
Flyer**

EN PDF 5.92 MB



**FH Series Vision System
- Sysmac Studio
Operation Manual**

EN PDF 11.9 MB



**FH Series Vision System
- Hardware
Setup Manual**

EN PDF 21.4 MB



**FH Series Vision System
- Macro Customize
Functions
Programming Manual**

EN PDF 5.96 MB



**FH-series Vision System
Datasheet**

EN PDF 11.7 MB



**FH/FHV Series
Communications
Settings
Communications
Manual**

EN PDF 13.2 MB



**FH/FHV Series Vision
System
Users Manual**

EN PDF 27.4 MB



**FH/FHV Series Vision
System - Processing
Item Function
Reference Manual**

EN PDF 38.6 MB



**FH/FHV Vision
Application Guide for
ABB robots
Practice Guide**

EN PDF 3.01 MB



**FH/FHV Vision
Application Guide for
Denso robots
Practice Guide**

EN PDF 2.93 MB



**FH/FHV Vision
Application Guide for
Epson robots
Practice Guide**

EN PDF 2.86 MB



**FH/FHV Vision
Application Guide for
Fanuc robots
Practice Guide**

EN PDF 3.02 MB



**FH/FHV Vision
Application Guide for
Omron robots
Practice Guide**

EN PDF 3.27 MB



**FH/FZ5 Series Vision
System
Users Manual**

EN PDF 43.2 MB



**FHV Series
Setup Manual**

EN PDF 26.6 MB




**FHV Software Inst 32bit
v651
Software**

EN ZIP 33.6 MB



**FH_Simulator_Launcher_v655
Software**

EN ZIP 90.8 MB



**FH_Simulator_Launcher_v66
Software**

EN ZIP 90.7 MB



**FZ5 Series Vision
System
Users Manual**

EN PDF 19.3 MB



**FZ5 Series Vision
System -
Communications
Settings
Users Manual**

EN PDF 18.4 MB



FZ5 Series Vision System - Hardware Setup Manual

EN PDF 19.4 MB



FZ5 Series Vision System - Macro Customize Functions Programming Manual

EN PDF 17.8 MB



FZ5 Series Vision System - Processing Item Function Reference Manual

EN PDF 26.7 MB



Murata CR-series Battery Safety Datasheet

EN PDF 385 KB



Selection Guide for Vision Sensors Brochure

EN PDF 991 KB



Traceability Solutions Toolbox Software

EN ZIP 6.05 MB